





www.furuno.com

FURUNO VOYAGER, next-generation bridge system, has been designed using our decades of expertise in sensor devices, network integration and software development. FURUNO VOYAGER bridge system offers multifunction workstations with seamless display of Radar/Chart Radar, ECDIS, Conning and Alert Management System data. FURUNO VOYAGER bridge systems have been developed with a completely new and intuitive user interface and in strict accordance with the most up-to-date safety and navigation standards in mind.

FURUNO VOYAGER, the next-generation bridge system

Total network sensor integration delivers enhanced situational awareness to the mariner. An uncomplicated display presentation simplifies and streamlines navigational tasks. Common responsibilities such as route planning, navigation status monitoring, log-keeping, alarm awareness and day-to-day chart management are made easy through common workstation layout and redundancy of display and control. Watchstanders will enjoy reduced workload and significant freedom to move about the bridge, with all necessary information available in a variety of displays and locations.



Multifunction display (MFD) capability

FURUNO Voyager offers workstations that combine flexibility and redundancy. Users may easily select ECDIS, Chart Radar, Conning display or Alert Management System at any multi-function display. Navigators will enjoy reduced workload and significant freedom to move about the bridge, with all necessary information available in a variety of displays and locations.

> Operator-preset conning display orientation can be summoned upon clicking on the dedicated buttons on the status bar.

Conning display

In the Conning display mode, sensor information and real-time navigation data are presented to navigators in a thoughtfully designed display presentation.

Information to be shown in the conning display:

- Heading Pitch and Roll Rudder angles Rate of Turn
- Position fix Speed (bow speed, longitudinal speed and stern speed)
- Propeller pitch Wind speed and direction (both true and relative)
- Thrusters pitch Alert list BNWAS indication Date and time, etc.





Alert Management System

Alert Management System presents and prioritizes alert status and information. The well designed display layout gives operators the ability to quickly identify alert situations, and the actions required to rectify the cause of the alert.

The Alert management System complies with MSC.302(87) Performance Standards for Bridge Alert Management.

ACTIVE ALERT



List of alerts currently active can be viewed.



By clicking on the **I** in the ACTIVE ALERT page, the list of icons used in the Alert Management System and their descriptions can be shown as a pop-up window.

Alertity Filter: Qi Alarm Qi Marring Qi Cuttorn Source Filter: Qi Alarm Qi Cuttorn Reternal New Source Source Filter: Qi Alarman Qi Cuttorn Reternal New Source New Source Plant: New Source New Source New Source New Source New Source New Source New Source New Source New Source New Source New Source Out New Source Source Counce New Source		Current Alert Alex 16015 1001 Deviation from Planned Rose						
Prenny Adet (1st) Source 0 Occurred Time (UTC) Ack (Time (UTC)	Priority Filter. 🛛 Alarm 🖉 Warning 🖉 Caution			Log Search:		Search		
Allem 001 Failure of Reduction in Rower State ECDID 1 11.59.03 Max/2011 11.59.03 Ma		-	< Page - 1/1			Dennet free		
Name O.O. No. 1 5/15 Control Prover Pail MADR.2 11/5 0/3 May 2011	-Frankry	Alert Toxi	Source	Occurred Time (UTC)	ACK Time (UTC)	Restified Time (UTC		
Name DG No.2 SrG Control Payeer Ital LCDS 2 1159 03 May 2011 1159 03				11-59 03 May 2011				
Name Odd No.3 S1G Costed Rower Roll FCDS 2 F158 03 May 2011 <thf158 03="" m<="" td=""><td>Alam</td><td>002 No.15/G Control Power Fail</td><td>RADAR 2</td><td>11:59 03 May 2011</td><td>11:59 D3 May 2011</td><td>11:59 D3 May 2011</td></thf158>	Alam	002 No.15/G Control Power Fail	RADAR 2	11:59 03 May 2011	11:59 D3 May 2011	11:59 D3 May 2011		
Name DD5 Nat. Actuator hall Hold Lock) AddMR 11/58 D3 Marz 2011 <td>Alarm</td> <td>003 No.2 S/G Control Power Fail</td> <td></td> <td>11:59 09 May 2011</td> <td></td> <td>11:59 03 May 201</td>	Alarm	003 No.2 S/G Control Power Fail		11:59 09 May 2011		11:59 03 May 201		
Warman DB No.2 Actuator hall Hind: Lock3 ECD61 11.59-03 May 2011 1	Alams	004 No.3 S/G Control Power Fail	ECDIS 2	11:59 03 May 2011	11:59 03 May 2011	11:59 03 May 2011		
Name 011 Addatabit hal MADM3 TTS 013 Name		005 No.1 Actuator Fail (Hyd. Lock)	RADAR 1	11:59 03 May 2011	11:59 03 May 2011	11:59 D3 May 201		
Warma 052 Ab.3. Actuator (e) Pred. Luck) LCD6.2 11.59.0.3 May 2011 11.59.0.0 May 2011 11.59.0.0 May 2011 <th< td=""><td>Warring</td><td>006 No.2 Actuator Fail UHvil. Lock)</td><td>ECDIS 1</td><td>11:59 03 May 2011</td><td>11:59 03 May 2011</td><td>11:59 03 May 2011</td></th<>	Warring	006 No.2 Actuator Fail UHvil. Lock)	ECDIS 1	11:59 03 May 2011	11:59 03 May 2011	11:59 03 May 2011		
Warming D31 Emmanages/D1 CPU Fail ECDs3 115 R03 Mary 2011 R03 R03 Mary 2011	warring	031 Autopilot Fail		11:59 03 May 2011	11:59 03 May 2011	T1:59 03 May 2011		
Warma D41 Endpairs AddAt 1 11:59:03 May 2011 11:	Warring	032 No, I Actuator Fail (Hed. Lock)		11:59 09 May 2011	11:59.03 May 2011	11:59 03 May 201		
Warring 042 Emergency-OA Auto Rudor Dutset Fiel ECD5.1 11.59-03 May 2011 11.59-03 M	Warning	033 Environcy-01 CPU Fall			11:59 02 May 2011	11:59 03 May 201		
Caston D41 Emerancy 05 Give Consests Invol All AADAR 2 F159(0) Nex 2011	Warning	041 Emergency-03 Memory(RDM) Fail	RADAR 1	11:59 03 May 2011	11:59 03 May 2011	11:59 03 May 2011		
Dauton 044 Einemencköld AUX Compass Healt Fall ECDS 2 1159 03 May 2011 1158 03 May 2011 1158 03 May 2011 1159 03 May 2011 <		042 Emergency-04 Auto Rudder Output Fall		11:59 03 May 2011	11:59 03 May 2011			
Guiden D45 Emergency-071 Find Back Fail FCD63 11.59.03 May 2011 11	Disting	043 Emersency 05 Gyro Compass Input Rall	RADAR 2	11:59 03 May 2011	11:59.03 May 2011	11:59 03 May 2011		
Caution OAB Enregence-OBB 3 Find Back Fail #ADMR 1 11:59:03 Mar/2011 11:59:03 Mar/2		044 Emergence 06 AUX Compass Inout Fail						
Caute 047 Emergency-06 3 Feed Back Fail ECDIS 1 11.59 03 Mar 2011	Citation	045 Emergency-07 1 Feed Back Fail		11:59 03 May 2011	11:59 03 May 2011	11:59 03 May 201		
Clusten 046 Emergency 111 Serva Locia Emeri RADAN 2 1159 03 May 2011 1159 03 May 2011 1159 03 May 2011		046 Emergency-08 2 Feed Back Fail	RADARIT	11:59 D3 May 2011	11:59:03 May 2011			
	Caution	047 Emergency 09 3 Feed Back Full	ECDIS 1	11:59 03 May 2011	11:59 03 May 2011	11:59 03 May 2011		
Gaution 049 Emergence 12.2 Sino Loop Error 1CDX5.2 11:59.03 May 2011 11:59.03 May 2011 11:59.03 May 2011		046 Emergency 11 1 Serva Loop Error	RADAR 2	T1:59 03 May 2011	11:59 03 May 2011	1159.03 May 2011		
	Caution	049 Emergency-12.2 Serve Loop Error	10052	11:59 03 May 2011	11:59.03 May 2011	11:59 03 May 201		
	Caution	051 Emergence-15 Link master Enter	RADAR 1	11:59 D3 May 2011	11:59 03 May 2011	11:59 D3 May 2011		

ALERT LOG

Alert history can be viewed in chronological order. The source of alerts, and the date and time each alert was raised, acknowledged and rectified are shown.

- 1 Listed alerts can be filtered by priority levels and alert sources.
- ² All the alerts listed on the displays can be acknowledged by clicking on "ACK All".
- ³ All the audible alerts can be silenced by clicking on "Silence".
- 4 The nature of the alert situation selected as well as remedy to rectify the alert situation is presented in the "Decision Support" area.

ALERT LIST



List of alerts available for each alert source can be viewed.

- ⁵ The latest active alert is displayed in the ALERT LIST and ALERT LOG pages.
- ⁶ Keyword search function is available in the ALERT LOG page, and the alert log can be exported to external use.

Track Control System permits automatic steering along the set route

FURUNO VOYAGER features Track Control System through integration of ECDIS and autopilot. This enables the vessel to keep on the plotted route automatically with minimum intervention from the navigator. This has been achieved through:

- Flexible steering control
- route planning on ECDIS
- enhanced position reliability through multi-tiered data validation process

The operator is alerted to navigational warnings and potential dangers before the vessel is at risk.



FURUNO's new user interface delivers straightforward, task-based operation



RCU-024





- A Common key assignment is arranged for the common tasks, such as EBL, VRM controls, on the control units of ECDIS and Radar/Chart Radar
- B Operation scheme close to a PC with the use of the trackball.
 - Trackball: to move the cursor and select an object
 - Left-click: to perform/confirm the action related to the selected object
 - **Right-click**: to display contextual menu while cursor is on the display area. and to cancel action done on the selected object

Scrollwheel: to select menu items

Task-based user interface realized by combination of Status bar and InstantAccess bar[™] providing quick access to the needed tasks/functions

FURUNO VOYAGER user interface includes carefully organized operational tools designed to make navigational tasks simple and easy. The "Status Bar" at the top of the screen clearly indicates operating mode and status and offers direct single-click control of the navigator's principle tasks. The Instant Access bar™ at the left of the screen provides direct control of the features and attributes of the on-screen presentation. These on-screen tools deliver straightforward, task-based operation with all multi-function display information in view at all times. The operator can quickly perform navigational tasks without having to enter intricate menus, thus losing situational awareness.

Contextual menu

Contextual menu contains all the available actions related to the position of the cursor, hence providing guick access to tasks required.



ECDIS

RADAR



FURUNO VOYAGER onboard navigation network system

FURUNO VOYAGER integrates the following two separate networks that link all the onboard navigation equipment, including multifunction displays and various sensors: Network for Integration and Interswitch and Network for Sensor Integration.

The navigation system consists of duplicated subsystems so that any loss of navigational functions can be avoided in an event of single point of failure. Since MFD is able to function as radar, ECDIS, conning information display and alert management system, navigation tasks can be performed from any of the interfaced multifunction displays, hence optimizing the system availability.

Network for Integration and Interswitch (Gigabit Ethernet) is used to communicate the following data:

- Radar interswitching
- TT and AIS target data
- Harmonization of databases (charts, routes, etc.)

Network for Sensor Integration (combination of 100 Base-TX Ethernet & IEC 61162-1/-2) is used to communicate the following data:

1

with Serial to network Cateways

- Sensor data
- Alert information

X-band radar antenna

Sensor Network

Sensor Adapters

Speed tog Anemaneter

Onioard sensors and network equipment.

GHO,

Nau C.S.



Sensor adapter

Sensor adapters act as central medium to gather all the sensor data and collectively feed it to all the workstations within the system. Individual cablings in the sensor-to-workstation interface can be greatly reduced. Since arrangement of the sensor adapters can be customized and extended to cover all the sensors within the system, thanks to its component configuration, flexibility can be assured when planning the network structure of the bridge system.





Beware of similar products

All brand and product names are registered trademarks, trademarks or service marks of their respective holders.

FURUNO ELECTRIC CO., LTD. Japan | www.furuno.com FURUNO U.S.A., INC. U.S.A. | www.furunusa.com FURUNO PANAMA S.A. Republic of Panama | www.furuno.com.pa FURUNO (UK) LIMITED U.K. | www.furuno.co.uk FURUNO NORGE A/S Norway | www.furuno.no

FURUNO DANMARK A/S Denmark | www.furuno.dk FURUNO SVERIGE AB Sweden | www.furuno.se FURUNO FINLAND OY Finland | www.furuno.fi FURUNO POLSKA Sp. Z o.o. Poland | www.furuno.pl FURUNO DEUTSCHLAND GmbH Germany | www.furuno.de

FURUNO FRANCE S.A.S. France | www.furuno.fr FURUNO ESPAÑA S.A. Spain | www.furuno.es FURUNO ITALIA S.R.L. Italy | www.furuno.it FURUNO HELLAS S.A. Greece | www.furuno.gr FURUNO (CYPRUS) LTD Cyprus | www.furuno.com.cy

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

FURUNO SHANGHAI CO., LTD. China | www.furuno.com/cn FURUNO CHINA CO., LTD. Hong Kong | www.furuno.com/cn FURUNO KOREA CO., LTD Korea

FURUNO SINGAPORE Singapore | www.furuno.sg

PT FURUNO ELECTRIC INDONESIA Indonesia | www.furuno.id FURUNO ELECTRIC (MALAYSIA) SND. BHD. Malaysia | www.furuno.my

> C-2210LB Catalogue No. CA000001683